

Fire Detector IR (0.00X)	X.00	X.00	X0
Fire Detector Ultraviolet	X.X0	X.X0	XX
Fire Detector Rate of Rise	X.00	.	X.00
Fire Detector Heat	X.X0	.	X.X0
Fire Detector Flame (0.00X)	X.00	X.00	X0
Smoke Detector General (0.00X)	X.X0	X.00	X0
Gas Detector IR (0.00X)	X.X0	X.00	X0
Gas Pellistor/Catalytic (0.00X)	X.00	X.00	X0
Chlorine sensor	X.00	.	X0
H2S sensor	X.00	X.00	X0
Oxygen sensor	X.00	X.00	X0
Zirconium oxide sensor	X.00	.	.
CO portable detector (0.0X)	X.00	.	.

Failure Modes :

Fire IR	Fail XX%	Spurious XX%
Fire UV	Fail XX%	Spurious XX%
Fire Rate of Rise	Fail XX%	Spurious XX%
Fire Heat	Fail XX%	Spurious XX%
Fire Flame	Fail XX%	Spurious XX%
Smoke	Fail XX%	Spurious XX%
Gas IR	Fail XX%	Spurious XX%
Gas Pellistor	Fail XX%	Spurious XX%
H2S Sensor	Fail XX%	Spurious XX%
Oxygen	Fail XX%	Spurious XX%
Zirconium oxide head	Fail XX%	Spurious XX%

Failure Mode

Mode 1

Mode 2

Component Ref.

Component Name

Comp't Failure Rate

Failure Mode 1

Fail. Mode Text

Fail. Mode Factor

Diagnostic Coverage %